



KEES, INC.

Products for Sheet Metal HVAC, Food Service, & Architectural Construction Industries

400 S. INDUSTRIAL DRIVE - P.O. BOX 327 - ELKHART LAKE, WISCONSIN 53020 - (920) 876-3391 - FAX (920) 876-3065

Mix^xer Section™ Installation Guide

Mix^xer Section Installation, Operation And Maintenance

Installation

The Mix^xer Section is manufactured complete with Air Mix^xer and flanges to match standard air handlers. Gasketing between Mix^xer Section and other air handling equipment should be used to seal against air leakage. The Mix^xer Section shall be match drilled in the field for proper fit up to standard air handling equipment.

Operation

Once installed, the Mix^xer Section, including Air Mix^xer, requires no operating instructions. The section utilizes a fixed position Air Mix^xer with no moving parts.

Maintenance

The Mix^xer Section is constructed of 18 gauge galvanized iron with heavy gauge aluminum (.080") Air Mix^xer and does not require any special maintenance under standard HVAC operation.